



Irisity Core Server

Pre-configured IRIS+™ solution to centrally manage up to 100 devices on-premise





The IRIS+™ Core Server

The Core Server is the center of IRIS+™ federated architecture. Install centrally and connect up to 100 cameras via IRIS+™ Edge appliances, in single or multi sites.

It is a pre-installed, and pre-configured management server, perfect for small to mid size installations, allowing a cost effective and fast deployment.

Whether you need to protect the perimeter of your remote sites, monitor a big manufacturing plant, or gather statistical insights from a shopping mall, the IRIS+™ Core Server is a unique solution to centrally manage and integrate into an existing cameras system and Video Management Software.

Activity Level	Number of cameras
Low	100
Medium	70
High	50

Remember to add the IRIS+ Edge 10 appliances to connect the cameras to the core.

See more here :

<https://iricity.com/products/edge-devices/>

Product Code	Name	Tech Spec
IRIS+™ Core Server	1U server designed for serving as an IRIS+™ Core management server in an on-prem installation, and connecting Edge 10 or Edge CI through the network	<ul style="list-style-type: none"> • Powerful 1U rack workstation • NVIDIA GPU • Gigabit ethernet • 2000GB SSD storage • Two redundant hot pluggable power supplies • Standard temperature range (10°C – 35°C) • HxWxD: 1.68" (42.8 mm) x 18.98" (482.0 mm) x 23.19" (589.1 mm) with Bezel or 22.74" (577.6 mm) without Bezel • ProSupport warranty by DELL

Video and metadata retention time is up to 30 days.